



### Incredibly easy to adjust.

Each fixture is conveniently factory-set at the most popular lumen level for maximum efficiency. To change, simply hold the included magnet over the lumen adjustment locator to begin the programming mode. The fixture will flash continuously four times and go dark before blinking to indicate which lumen level is currently programmed. Programming begins from the factory setting and adjusts up in lumens (Level 1 for Large Accent, Level 2 for Small Accent).

VLO Adjustment Settings		Small Accent	Large Accent
Level 1	1: Flashes once <i>included switching magnet</i>	100 lm	*400 lm
Level 2	2: Flashes twice	*200 lm	600 lm
Level 3	3: Flashes three times	300 lm	835 lm

\*Factory setting

### (VLO) Variable Lumen Output



Level 1

Level 2

Level 3

12V LED Small Accent	
Level 1	<b>100 Lumens</b> (shown: 16016 Small Accent, 35° Flood, 2W, 3000K)
Level 2*	<b>200 Lumens</b> (shown: 16016 Small Accent, 35° Flood, 3.5W, 3000K) *Factory setting
Level 3	<b>300 Lumens</b> (shown: 16016 Small Accent, 35° Flood, 5.5W, 3000K)



12V LED Large Accent	
Level 1*	<b>400 Lumens</b> (shown: 16019 Large Accent, 35° Flood, 6W, 3000K) *Factory setting
Level 2	<b>600 Lumens</b> (shown: 16019 Large Accent, 35° Flood, 11W, 3000K)
Level 3	<b>835 Lumens</b> (shown: 16019 Large Accent, 35° Flood, 16W, 3000K)

Note: Beam width/cut-off is dependent on how close the fixture is to the object. Lumen levels are the same for 2700K and 3000K.